




SPARE PARTS LIST

CRYO 170





Pos. no.	Code no.	Part	Recommended	
1	-	Cabinet		

2	-	Handle catch (included handle)		
3	5052142-01	Outer lid (door) CRYO 230		
4	5052144-01	Gasket CRYO 230		
5	-	Lid inner liner (included outer liner)		
6	5052146-02	Sub lid CRYO 230 (set of 2 pcs.)		
7	5051063-01	Handle	x	
7a	5051068-01	Key for handle		
8	5031203-01	Caster frame		
9	5031254-01	Caster frame - front		
9.1	5053028-01	Caster		
10	5032014-01	Adjuster bolt - After march 2015		
10	5032015-01	Adjuster bolt - Before march 2015		
11	5031204-01	Hinge		
12	5031205-01	Access port ø50		
13	5031206-01	Spacer		
14	5031207-01	Machine room frame		
15	5043015-01	Control panel		
16	5031208-01	Machine room stand		
17	5010044-01	Ventilator		
18	5031209-01	Top cover		
19	5040034-01	Temperature controller TTM004-RA-Z223	x	
20	5019142-01	Lamp ø16 AC/220V		
21	5019143-01	Switch WJT-2210S		
22	5031210-01	Hinge for control panel cover		
23	5051064-01	Lock & Key (set)		
24	5030093-01	Control panel cover		

Arctiko reserve the right to change prices at any time without further notice.

43	5019149-01	Outlet (100V) WK 1012	
25	5031211-01	Back cover	
26	5071045-01	Block condenser	
27	5010045-01	Fan motor UF25GC23BTH	x
27.1	5031232-01	Fan motor bracket	
28	5070114-01	Compressor TS370J1N (CRYO 230-0)	x
28	5070129-01	Compressor YS-480J2N (CRYO 230)	x
29	5079030-01	Dryer DML032S	x
30	5031212-01	Side cover	
31	5031213-01	Panel for electric parts	
32	5032016-01	Magnet S/W	
33	5019144-01	Transformer 50VA	x
34	5040035-01	Controller (for LN2) FOX-2P1-D	
35	5044013-01	Battery NPH5-12V	
36	5019145-01	Battery charger P1210TR	
37	5019146-01	Buzzer EB2122 DC12V	
38	5019147-01	Push button (for LN2) SB-4011 N/O	
39	5011012-01	Relay 2C 220V, HR705-2P	
40	5011013-01	Time relay H3Y-2C 30sec.	
41	5011014-01	Time relay B4S-4 60sec.	
42	5019148-01	Relay socket 2C 5A, AC/250V	

Pos. no.	Code no.	Part	Recommended
44	5019150-01	Terminal Stand 20A*10P	
45	5042026-01	Sensor PT-100	x
46	5031214-01	Sensor pipe cover ø9.52 L-220mm	

Arctiko reserve the right to change prices at any time without further notice.

47	5031215-01	Expansion tank 6" * 500mm	
48	5019152-01	Solenoid valve EVR-2S	
49	5019153-01	Pressure switch SNC-C130	
50	5019154-01	Terminal stand 20A*2P	
51	5074018-01	Oil separator HFOS-076	
51.1	5074019-01	Oil separator assembly	
52	5074016-01	Heat exchanger L-120mm	
53	5019155-01	Relay 4C 220V, SZR-MY4-N1	
54	5019156-01	Relay socket 4C SZX-SMF-14N	
55	5070115-01	Sensor cover 500*54*0.8t	
56	5019157-01	Solenoid valve (for LN2) 8263G240LT DC12	
57	5019158-01	Wire hose (for LN2) 3M	
58	5019159-01	Door limit switch (for LN2) GLS-S1	
59	5019160-01	Check valve (for LN2) 125-R	
60	5019161-01	Thermostat switch 70R	x
61	5042027-01	Sensor for recorder PT-1000	x
62	5019162-01	LN2 Injection cover (for LN2) SUS 1.0t	
63	5019163-01	Power cable plug 4C 2.5S (AC/220V)	
64	5019194-01	Terminal Stand 20A*3P	
65	DAI 0937	Chart recorder	
65a	5051067-01	Key and lock for chart recorder	
-	-	Refrigerant EP88 →R14→CH4→Ar	

5087150-05

Arctiko A/S

Lammefjordsvej 5 · DK-6715 Esbjerg N · Phone: +45 7020 0328

info@arctiko.com ■ arctiko.com

